


NEW LAND

New Generation of Appliance



دستگاه تصفیه آب
مدل: NL-3030BW

فارسی ☐
English ☐

راهنمای استفاده از دستگاه تصفیه آب:

توجه:

۱. در اولین استفاده از دستگاه تصفیه آب، ممکن است پودر سیاه کربن فعال در آب، شناور شود. قبل از قرار دادن فیلتر روی جایگاه، آن را تمیز کرده و اجازه دهید این آب سیاه خارج شود.

۲. دستگاه تصفیه آب را در معرض نور مستقیم خورشید قرار ندهید.

۳. آب قابل استفاده در دستگاه تصفیه آب شامل آب شیر، آب چشمه، یا آب تمیز رودخانه‌ها و دریاچه‌ها است. لطفاً از آب آلوده استفاده نکنید؛ زیرا عمر مفید فیلتر را کاهش می‌دهد.

۴. سطح آب فیلتر شده باید به اندازه‌ای باشد که فیلتر را بپوشاند. این فیلتر حاوی مواد خاص مادون قرمز دور و مواد مغناطیسی است که می‌تواند باعث افزایش فعال‌سازی زیستی، مواد معدنی و از بین بردن باکتری‌های موجود در آب شود.

۵. در صورتی که بیش از یک هفته از دستگاه تصفیه آب استفاده نمی‌کنید، بهتر است تمام آب تصفیه شده موجود در مخزن پایینی را خالی کنید.

۶. اگر کاربران پس از تصفیه‌ی ۲۰۰ تا ۳۰۰ لیتر آب، سرعت فیلتراسیون را کند دیدند، لطفاً لایه بالایی فیلتر را که از الیاف کربن فعال و پارچه فیلتراسیون تشکیل شده، خارج کرده و آن را بشویید یا با فیلتر دیگری که ما در اختیار شما قرار می‌دهیم، تعویض کنید.

۷. لطفاً فیلتر اصلی را پس از یک سال استفاده یا در صورت نیاز تعویض کنید.

۸. هنگامی که مخزن پایینی پر از آب شد، دیگر آب بیشتری اضافه نکنید.

عیب یابی

مشکل	دلیل	راه حل
آب نشت می کند.	۱. شناور توپی از جای خود جدا شده است.	۱. شناور توپی را به درستی ببندید.
	۲. سینی آب سردکن بیش از حد کم عمق است.	۲. فیلتر آب سردکن یا دستگاه تصفیه آب جدید بخرید.
	۳. آلودگی روی شیر سر شناور توپی باعث اختلال در عملکرد آن شده است.	۳. در صورت نیاز، شیر سر شناور توپی را تمیز کنید.
	۴. سطح آب بندی مرکزی سوپاپ شناور توپی از جای خود خارج شده است.	۴. سطح آب بندی هسته شیر را در جای خود نگه دارید.
در بخش پایین آبی جمع نشده است.	۱. لایه بالایی فیلتر به دلیل تمیز نشدن برای مدت طولانی مسدود شده است.	۱. با توجه به جزئیات آن را بشویید یا تغییر دهید
	۲. فیلتر اصلی مسدود شده است.	۲. المنت فیلتر جدید را تغییر دهید.
آب داغ و سرد ترکیب شدند.	۱. آب سردکن دچار مشکل شده است.	۱. آب سردکن را تعمیر کنید
	۲. موقعیت سوراخ هواکش داخل آب سردکن خیلی پایین است.	۲. فیلتر آب سردکن یا دستگاه تصفیه آب جدید بخرید.

معرفی کوتاه دستگاه تصفیه کننده آب

دستگاه تصفیه کننده آب مدل NL-3030BW یک دستگاه پیشرفته تصفیه، مواد معدنی سازی و فعال سازی آب آشامیدنی است که حاصل دستاوردهای علمی پیشرفته داخلی و خارجی می باشد. ویژگی اصلی این دستگاه امکان استفاده مستقیم و داشتن خروجی آب است.

این دستگاه مجهز به فیلترهای چند لایه برای استریلیزاسیون، جذب، فیلتراسیون و مواد معدنی سازی و غیره است. آب معمولی شیر از طریق یک ستون فیلتر ۲۰۰ میلی متری پر شده با کربن فعال نقره ای، سیلیس فعال و غیره جذب و فیلتر می شود. این دستگاه به طور مؤثر می تواند ناخالصی های معلق، کلر، فلزات سنگین و مواد مضر موجود در آب را از بین ببرد. یون های نقره که به آرامی در آب آزاد می شوند، خاصیت استریلیزاسیون طولانی مدت داشته و از تکثیر باکتری ها جلوگیری می کنند.

توپ های مادون قرمز دور و مواد معدنی ساز که به صورت گرانول هستند، حاوی بیش از ۲۰ نوع ریزمغذی های ضروری بدن مانند روی، لیتیوم، ید و سلنیوم و غیره می باشند. تحقیقات علمی نشان داده است که این گرانول ها به آرامی و به طور مساوی در آب تصفیه شده توسط این دستگاه حل می شوند و باعث می شوند آب نسبت به آب تصفیه شده معمولی دارای عناصر معدنی ضروری بیشتری باشد. توپ های مادون قرمز دور و مواد معدنی ساز نیز می توانند عملکرد فعال سازی را انجام دهند. تشعشعات مادون قرمز دور باعث شکسته شدن مولکول های بزرگ به مولکول های کوچک شده و در نتیجه میزان اکسیژن و فعالیت زیستی آب را افزایش می دهد.

این آب بدون نیاز به جوشیدن قابل مصرف است.


با مصرف طولانی مدت، کاربران متوجه می شوند که این آب تصفیه شده می تواند عملکردهای بدن را تنظیم کند، سیستم ایمنی را تقویت کند، از سنگ کلیه پیشگیری و آن را درمان کند، داخل رگ های خونی را پاکسازی کند، متابولیسم را بهبود بخشد، از

بیماری های پوستی پیشگیری و آن را درمان کند و به طور خاص از سندرم کمبود مواد معدنی ناشی از مصرف بیش از حد آب تصفیه شده معمولی جلوگیری کند.

عمر مفید فیلتر تصفیه کننده ۳۰۰۰ لیتر آب شیر است. کاربران می توانند در صورت نیاز به راحتی فیلتر اصلی را خودشان تعویض کنند. لطفاً قبل از تعویض فیلتر، اطلاعات دقیق را مطالعه کنید.

مدل NL-3030BW :

۱. برای تمیز کردن فیلتر، آب را داخل آن بریزید تا آب خروجی تمیز شود.
۲. شناور تویی را روی سر شیر بپیچانید (تصویر ۱).
۳. درپوش هوشمند خروجی آب را بردارید (تصویر ۲).
۴. دستگاه تصفیه کننده آب را به درستی روی خروجی آب نصب کنید (تصویر ۳).



تصویر ۱



تصویر ۲




تصویر ۳

دستورالعمل جداسازی و شستشو:

مدل: NL-3030BW

۱. درپوش بالایی را جدا کنید.
۲. درپوش فیلتر بالایی را بردارید، الیف فیلتر داخل آن را بشویید یا تعویض کنید (تصویر ۴).
۳. عنصر فیلتر را می‌توانید خلاف جهت عقربه‌های ساعت بچرخانید و جدا کنید.



Notes

1. Black activated carbon powder will suspend in water when the water purifier is first used. Clean the filter element and let this black water flow out before putting it onto the dispenser.
2. The water purifier must be placed without direct sunlight,
3. Water filled into the water purifier can be tap water, brook water, or clean water from rivers or lakes. Please do not use dirty water, which will shorten the service life of the filter element.
4. The filtrated water surface should be high enough to dip the filter element, in which there are special far infrared materials and magnetization materials, which can increase biologic activation, mineral elements and kill bacteria in water.
5. It's better to let out all purified water in the under container if the user has stopped using it for over a week.
6. If users find the speed of water filtration slow after 200-300 litres water has been used, please take out the top layer of the filter element, composed of activated carbon fibre and filtration cloth. Wash it or change it with another one we supply.
7. Please change the main filter element after one year's use or when need.
8. Do not pour water in any more when the under container is full of water.

Trouble shooting

Trouble	reasons	solutions
Water leaks	1. the ball float falls off	1. Screw on the ball float.
	2. the trough of dispenser is too shallow	2. change a new type dispenser or water purifier
	3. impurity on the head valve of ball float	3. clean the head valve of ball float
	4. the valve core sealing surface of ball float is out of place	4 keep the valve core sealing surface in place
No water down	1. top filter layer jams without cleaning for long time	1. wash or change it referring to detail information
	2. the filter element jams.	2. change a new filter element
Cold and hot water composite	1. dispenser trouble	1. fix the dispenser
	2. position of the blowhole inside the dispenser is too low	2. change a new type dispenser or water purifier

Brief Introduction

Water purifier model NL-3030BW is up-to-date drinking water appliance in purification, mineralization and activation, referred to domestic and overseas advanced scientific fruit. Its main characteristic is that this appliance can be used directly with water dispenser.

The appliance is install with multi-layer group wares for sterilization, adsorption, filtration and mineralization, etc. General tap water is adsorped and filtrated through a 200 mm long filter pole filled with silver activated carbon and activated silex sands, etc. It can effectively wipe off suspendedimpurities, chlorine, heavy metals and injurant in water. The silver ion, which slowly separate out to the water, can do the function of long-term sterilization, restraining bacteria to propagate and so on. Far infrared and mineralizing ball, which is refined to be granules, collect more than 20 kinds of sanative microelements such as Zincum, Lithium, lodin and Selenium etc. Scientific research indicate that these granules separated slowly and equably out to water purified by this appliance will make the water have more sanative mineral elements by comparing with general pure water. Far infrared and mineralizing balls. can also do activation function. Large molecule group will be split to be small one by far infrared radiation, which will increase the amount of oxygen and increase biologic activation of water. This water can be directly drunk without boiling

After a long-term drinking, users will find that this purified water can adjust body functions, improve immune abilities.prevent and cure viscera calculus, clean the inside of blood vessels, promote metabolism, prevent and cure dermatosis etc. Specially, it can prevent syndrome of mineral element shortage caused by excessive drinking of general pure water.

Service life of the filter element is: purifying 3000 litres tap water. Users can change the main filter element conveniently by themselves when need. Please read the detail information before changing it.

Model No.: NL-3030BW

1. Pour in water to clean the filter element until water become clean.
2. Screw the ball float onto the valve seat (illustration 1).
3. Remove the clever seat of the dispenser (illustration 2)
4. Put the water purifier onto the dispenser correctly (illustration 3).




illustration 1




illustration 2



illustration 3

Unpicking and washing:

Model No.: NL-3030BW

1. Remove the top lid.
2. Remove the top filter cover, wash or replace the filter fiber in it (illustration 4).
3. The filter element can be screwed off counter-clockwise.





illustration 4



QUALITY EXPERIENCE



Water Purifier
Model: NL-3030BW

فارسی ☐
English ☐